

Message Number	Description	Preamble Tone	Duration(s)	Message Text
0	Off			
1	Female evacuation	AUS/NZ Evacuation Tone	7.5	Attention, attention. This is an emergency. Please Evacuate Now by the nearest available exit
2	Female alert	AUS/NZ Alert Tone	7.5	May I have your attention please, an incident has been reported in the building please listen for further instructions
3	Female evacuation V2	AUS/NZ Evacuation Tone	7.5	Attention, attention. This is an emergency. Please leave the building by the nearest available exit
4	Female test	AUS/NZ Evacuation Tone	3.5	This is a test message, no action is required
5	Male evacuation	AUS/NZ Evacuation Tone	7.5	Attention, attention. This is an emergency. Please Evacuate Now by the nearest available exit
6	Male alert	AUS/NZ Alert Tone	8.1	May I have your attention please, an incident has been reported in the building. Please listen for further instructions
7	Male test	AUS/NZ Evacuation Tone	4	This is a test message, no action is required
8	Bell (accessed via msg 14/15)	None	Until Stopped	None
9	No tone or message	None	0	Used by control panel to allow user to 'turn off' sounder part of a talking sounder beacon
10	Unused, defaults to message 1	AUS/NZ Evacuation Tone	7.5	None
11	Warble electronic tone	None	Until Stopped	None
12	Pulsed electronic tone	None	Until Stopped	None
13	Continuous electronic tone	None	Until Stopped	None
14	Pulsed bell	None	Until Stopped	None
15	Continuous bell	None	Until Stopped	None

NOTE: Preamble Tone type dependant on product installed.

The preamble tone is played for 4 seconds, then a 1 second silence, then the message, then silence until the sequence is re-triggered. This sequence trigger is global and panel adjustable; preset to 20 seconds. Messages 12 and 14 pulse at a rate determined by Super Group 1 pulsing (standard sounder pulse rate). Messages 1 to 8 (inclusive) pulse at a rate determined by Super Group 2 pulsing (dedicated to talking sounders). Remaining messages are continuous until silenced.

Company Policy is one of continuous improvement, we reserve the right to change specification without prior notice

**Bosch Security Systems Pty Ltd, Suite 1, Level 2, 21 Solent Circuit, Baulkham Hills, NSW 2153, Australia**

**Tel: +61 02 9842 4700 Web: [www.protec.co.uk](http://www.protec.co.uk) Email: [protecanz.info@au.bosch.com](mailto:protecanz.info@au.bosch.com)**

© 2024 Bosch Security Systems Pty Ltd